

**Precision Shooting Accessories** 

## COVER REMOVAL TECHNIQUE for Tech-SIGHTS AK CONVERSION



1. Grasp the rifle with your hand over the cover.



2. While squeezing firmly down on the cover, depress the detent with a pointed object until the cover disengages and drops slightly down below the detent.



3. Continue firm steady pressure on the cover to hold it in position while you roll the rifle with the ejection port side up and depress the cover detent on that side until the cover disengages the detent and drops slightly below the detent.



4. With the two detents disengaged the cover can now be slid back and out of the cover retention groove on the front of the receiver. Keeping the detent holes in the cover just below the detents, pull the cover ahead and off the rifle.